

# QUICK START GUIDE

## Table of Contents

Starting the simulator .....	3
GolfIn Launcher .....	4-5
Game Modes .....	6-18
IDRA II Functions .....	19-21
Closing the simulator .....	22-23

### Simulator Startup Steps

Before you begin your game, follow these simple steps to start the system:

#### 1. Turn on the IDRA camera light

- ▶ Use the switch located on the wall, near the simulator.
- ▶ If there is no switch on the wall, use the joystick (often attached to the touchscreen).



#### 2. Check if the computer is turned on

- ▶ If the computer is off, press the power button (often located on the front or top of the tower).

#### 3. Turn on the computer screen (monitor)

- ▶ Press the power button on the monitor (touchscreen), usually located on the back, on the front, or under the screen.

#### 4. Turn on the projector

- ▶ Use the projector remote control to turn it on.
- ▶ Wait a few seconds: the computer image should appear on the simulator canvas.




- ✔ You should now see the computer screen projected onto the canvas.
- ✘ If not, check again that **each component is switched on.**

**Once the image is projected onto the canvas:**

**1. Make sure you are on the GolfIn Launcher**

- ▶ The GolfIn Launcher opens automatically.
- ▶ If not, find the "GolfIn Launcher" icon on your computer desktop and double-click it.




## 2. Select the available game

► On the screen you will see the game(s) you have access to.

For example :

o If GSPRO is your only license, only that game will be displayed.

o If you have access to multiple games (eg: E6 Connect, Multisport), they will also appear in the menu.




✓ Click on the displayed game to launch it.

### Game Mode – Practice

Practice mode allows you to practice without playing a full game. You have two main options:

- ▶ Practice Range
- ▶ On course Practice



## Practice Range

Once **Practice** is selected from the main menu, click on **Practice Range**. You will be automatically transported to the GSPRO Practice Range.

**No player needs to be selected.**

✓ You can hit balls freely, at your own pace.



👉 Important :

If the ball is not detected, a red icon will appear at the bottom of the screen with the word "Not Ready".

As soon as this icon **disappears**, it means that the ball is correctly positioned and that the **IDRA II camera is ready** (the ball must be in the striking zone on the ground which is 18" X 32").

✅ You can then hit.



**To exit:**

1. Click on the four small dots ( :: ) at the top right of the screen.
2. Then click End Round to return to the main menu.




### On Course Practice

Once **Practice** is selected in the main menu, you can also click **On Course Practice**.




This option allows you to:

#### 1. Choose a golf course (Course)




2. Select a specific hole on this course


- ▶ You can practice shots as if you were on a real course, but in free mode.
- ▶ It works similarly to the Practice Range, but with the setting and layout of a real golf hole.



3. Start the game by pressing PLAY in the bottom right corner.



**Game Mode – Local Match**



To play a full or partial round of golf:

**1. From the main menu, select Local Match**

► This mode allows you to play 18 holes, 9 holes or a custom number of holes on a specific course.

**2. Choose a golf course (Course)**


► A list of lands appears on the screen.

You can :


- Click on a displayed route
- Or use the search bar to find a specific one

### 3. Use the filters (on the right of the screen)


- Installed: Displays only the already installed terrains




- All Courses: Displays all available courses (requires download)



- Play Random Course: Launch a random course



- Reset Filters: Reset the filters if necessary



**4. Select the desired land**


► Once found, click Play to proceed to game setup.

**5. Add or select players**

After clicking Play: A screen for player management appears.


**If the player already exists:**

► Select it from the drop-down menu.



**If the player does not already exist:**


- ▶ Click Create Player (at the bottom of the screen), enter a name, select the orientation (Right-Handed / Left-Handed), and save.




### Game Settings

Before starting the game, you can adjust the following settings:

- Match Settings: Change the format (Stroke Play, Match Play, etc.), putting mode, tees, weather, etc.



- Holes: Choose the holes to play (Front 9, Back 9, All 18, custom holes)



- ✓ Once players are added and settings are complete, click Play at the bottom right to start the game.

**Before you hit your first shot**

When the game has started:

- At the top left of the screen, you will see the name of the active player (the one who must strike).



- Make sure the ball is placed in the hitting zone (the hitting zone on the ground is 18" X 32").




**Useful functions during the game**

Here are some convenient options available during a Local Match:

**🔄 Mulligan (Turn ON in Match Settings before launching a Local Match)**

If you miss a shot or make a mistake, you can replay without penalty.

- Click on the IDRA tile at the top of the screen.
- Then click on Mulligan.




### Enable or disable video replay (Shot Analyzer)

By default, a video replay of the shot is displayed after each strike. You can disable this feature at any time:

- ▶ Click on the IDRA tile at the top of the screen.
- ▶ Then click on Disable Shot Analyzer.

To reactivate the video:

- ▶ Repeat the same steps, then click Enable Shot Analyzer.



### Change alignment (aim)

By default, the game aligns your shot towards the flag. To change the direction:

- ▶ Click directly on the screen where you want to aim. This will change your alignment for the next shot.


**⚠ Caution:** Automatic alignment can sometimes direct you straight to the flag, without taking into account obstacles (trees, lakes, bunkers, etc.). Remember to adjust manually if necessary.

**🔄 Reset the camera if there is a problem**

In case of a problem (e.g. the camera does not detect the ball even if it is well placed in the hitting zone), it is possible to reset the IDRA camera without restarting the entire system:

- ▶ Click on the IDRA tile at the top of the screen.
- ▶ Click Reset.

This will restart the camera, and most issues should fix themselves automatically.



### Close the game and turn off the simulator

When you are finished with your session, follow these steps to properly shut down the simulator:


#### 1. Quit the current game

- ▶ Click on the drop-down menu (the four small squares at the top right of the screen).
- ▶ Select End Round to exit the match or practice mode.



## 2. Close GSPRO

- Once you return to the main menu, click on Exit (top left of the screen).



## 3. Turn off the computer

- Access the Windows menu.
- Click Power > Shut down to turn off the computer.

## 4. Turn off remaining devices

- Projector: Use the remote control to turn it off.
- IDRA camera light: Use the wall switch or the controller attached to the computer screen to turn it off.

- ✅ This procedure ensures safe closure and extends the life of the equipment.